



LAMPADA FLEXLED

PROFESSIONALE

RICARICABILE - ART. 62570



IMPORTANTE: Leggere attentamente queste istruzioni prima di utilizzare la lampada.

DATI TECNICI

- Corpo: alluminio + PC + gomma
- Potenza LED: 5W COB + 1W torcia
- Lumen: 550 lm frontale principale + 140 lm lampada ispezione
- Temperatura colore LED: circa 6500 K.
- Ingresso di ricarica: 5V 1A
- Alimentazione: cavo Micro-USB da 1,0 metro
- Batteria: 3,7 V 2500 mAh Li-ion
- Tempo di ricarica: circa 4-5 ore
- Tempo di funzionamento:
 - Circa 2,5 ore di illuminazione al 100% della potenza (level 1)
 - Circa 5 ore di illuminazione al 50% della potenza (level 2)
 - Circa 12 ore di illuminazione al 10% della potenza (level 3)
 - Circa 10 ore di illuminazione con solo luce ispezione.

INTERRUTTORE FUNZIONE

- 1: premere 1 volta: LED principale anteriore acceso al 100%
- 2: premere 2 volte: LED principale anteriore acceso al 50%.
- 3: premere 3 volte: LED principale anteriore acceso al 10%
- 4: premere 4 volte: luce di ispezione accesa
- 5: premere 5 volte: OFF

Se lasciata in qualsiasi modalità per oltre 3 secondi, la pressione successiva spegne la luce.

MISURE DI SICUREZZA

- Non utilizzare la lampada nelle immediate vicinanze di materiali o gas infiammabili.
- Utilizzare solo gli accessori inclusi con il prodotto.
- Tenere la lampada fuori dalla portata di persone non autorizzate, in particolare bambini.
- Non puntare la luce direttamente nei propri occhi o negli occhi di altre persone o animali.
- Controllare sempre il cavo di alimentazione prima di utilizzare la lampada.
- Se il cavo di alimentazione è danneggiato, deve essere sostituito.

PULIZIA

Prima di pulire le luci a LED, scollegare il cavo di alimentazione e lasciare che la lampada si raffreddi sufficientemente, pulire con un panno asciutto o leggermente umido, pulito e privo di lanugine e, se necessario, un detergente delicato. Non utilizzare detergenti contenenti abrasivi o solventi.

MANUTENZIONE

- Controllare che la spina, il cavo di alimentazione e l'alloggiamento della lampada non siano danneggiati prima di ogni utilizzo.
- Rimuovere immediatamente lo sporco dall'alloggiamento o dall'obiettivo, poiché potrebbe causare il surriscaldamento.






LAMPADA FLEXLED

PROFESSIONAL

RECHARGEABLE - cod. 62570



IMPORTANT: Read these instructions fully before using the Floodlight. Retain these instructions for future reference.

TECHNICAL DATA

- The body: Aluminium + PC+ Rubber
- LED 5W COB +1W torch
- Lumen 550 lm main front + 140 lm torch
- LED Color temperature: approx 6500K
- Charging input: 5V 1A
- With 1.0 m Micro-USB cable
- Battery 3.7V 2500mAh Li-ion
- Charging Time: Approx 4-5 hours
- Operation Time:
 - Approx 2.5h lighting for switch to 100%
 - Approx 5h lighting for switch to 50%
 - Approx 12h lighting for switch to 10%
 - Approx 10h lighting for switch to Torch.

SWITCH FUNCTION

- 1: Press 1 times: Front Main LED ON 100%
- 2: Press 2 times: Front Main LED ON 50% .
- 3: Press 3 times: Front Main LED ON 10%
- 4: Press 4 times: Torch ON
- 5: Press 5 times: OFF

If left in any mode for over 3 seconds , the next press will turn the light off.

SAFETY PRECAUTIONS

- Do not use the lamp in the immediate vicinity of inflammable materials or gases.
- Only use the accessories included with the product .
- Keep the lamp out of reach of unauthorised persons, especially children.
- Do not point the light directly in your own or any other person's or animal's eyes.
- Always check the mains cable before you use the lamp.
- If the supply cord is damaged, it shall be replaced by a similar qualified person in order to avoid a hazard.

CLEANING

Before cleaning the LED floodlight, disconnect the power cable and allow the floodlight to cool down sufficiently, clean with a dry or slightly moist, clean, lint-free cloth and a mild detergent if required. Do not use cleaners that contain abrasives or solvents.

MAINTENANCE

- Check the plug, power cable, and housing of the LED floodlight for damage before each use.
- Clean any dirt from the housing or the lens immediately, since it could cause overheating.



This symbol means that the product should not be disposed of a household waste at the end of its working life (As directive 2012/19/UE). It has to be taken to a special local differentiated waste collection centre, following your country's rules, or redelivered to the distributor when buying a new appliance. Correct disposal of this product will help prevent negative consequences for the environment and human health.

